

Four digit digital countdown timer, with encoder as input for small display 1 second to 99 minutes and 59 seconds

Datasheet

Version: Firmware 1.76-138





StefPro UG (haftungsbeschränkt) & Co. KG

Theilenmoorstr. 11 26345 Bockhorn, Germany

Phone: +49-4452-709175 Web: https://www.stefpro.biz/ E-mail: info@stefpro.biz




Table of Contents

Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 15 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19	Table of Contents	2
Application and function description 5 Function description 5 Function description 5 Function a states 6 Construction description 7 Pin assignment 7 Reast 7 Reast 7 AVCC 7 N.C. 7 TREE 7 AVCC 7 N.C. 7 TREE 7 N.C. 7 TREE 9 DST DSSEG_S.SEG_D. SEG_F. SEG_F. SEG_G. SEG_DP 8 BEZER 8 BEZER 8 BEZER 8 Properties of the components 10 7 segment displays 10 Chockade the senter relation for one LED 12 Clackade the senter relation for one LED	Safety	4
Function description 5 Application Functions 5 Application 5 Functional datase 6 Technical datase 6 Technical datase 7 Technical data 7 Construction description 7 Pin assignment 7 Reset 7 Reset 7 AVCC 7 ANEE 7 CND 7 TRA BEST IS DISH 8 SEG A, SEG B, SEG C, SEG D, SEG F, SEG G, SEG DP 8 SEG A, SEG B, SEG C, SEG D, SEG F, SEG G, SEG DP 8 SEG A, SEG B, SEG C, SEG D, SEG F, SEG G, SEG DP 8 SEG A, SEG B, SEG C, SEG D, SEG F, SEG G, SEG DP 8 SEG A, SEG B, SEG C, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG B, SEG C, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG B, SEG C, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG F, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SEG G, SEG D, SEG G, SEG DP 8 SEG CA SEG D, SEG G, SEG D, SE		
Functions		
Application Functional states 6 Functional states 7 Functional sta		
Technical data		5
Construction description 7 Pin assignment 7 Reset 7 AVC 7 AVC 7 AREF 7 GND 7 Q1, Q2 7 N.C. 7 TiRe 8 DIST to IDS4 8 SEG_A, SEG_B, SEG_C, SEG_D, SEG_E, SEG_F, SEG_G, SEG_DP 8 Buzzer 8 Buzzer 8 Basic circuit 9 Properties of the components 10 7 segment displays 10 7 segment displays 10 Calculate the series resistor for one LED 12 Calculate the series resistor for one LED 12 Calculate the series resistor for two LED 12 Keyboard 13 Button functions 13 Relaits 13 Button functions 13 Button description 14 Button functions 14 Menu 14 Ling the		
Pin assignment		6
Rissel		
VCC AVCC 7 AVCC 7 AVEF 7 GND 7 OI, 02 7 N.C. 7 TRa 8 BCS LOSEG B, SEG C, SEG D, SEG E, SEG F, SEG G, SEG DP 8 BLUZER 8 B Buizer 8 TB 8 Basic circuit 9 Properties of the components 10 7 segment displays 10 Obecked displays 10 Effect of an actylic glass 10 Calculate the series resistor for two LED 12 Keyboard 13 Button functions 13 Rotary encoder 13 13 Relais 13 Button description 14 Button description 14 Using the Countdown Timer - Outside of menu 14 Using the Countdown Timer - Outside of menu 14 End at up pause 15 Ent at up pause 15 Ent at up pause 15<		
AVCC AREF AREF GND G1, Q2 7 N.C 17 N.C 7 TIRe BST to IDI4 8 BST to IDI4 8 SEG A, SEG B, SEG C, SEG D, SEG E, SEG F, SEG DP 8 BLWZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZ		
AREF GND GND GND GND GND GNC TGR NC TIRE BSST to DISA SEG A, SEG B, SEG C, SEG D, SEG E, SEG G, SEG DP 8 SEG A, SEG B, SEG C, SEG D, SEG E, SEG G, SEG DP 8 BLZZEF 8 BBLZZEF 8 BBSLIC CIRCUIT 9 Properties of the components 10 Checked displays 10 Checked displays 10 Checked displays 10 Calculate the series resistor for one LED 12 Calculate the series resistor for two LED 12 Keyboard 13 Button functions 13 Button functions 13 Buzzer properties 13 Buzzer properties 13 Button functions 14 Using the Countdown Timer - Outside of menu 14 Using the Countdown Timer - Outside of menu 14 Using the Countdown Timer - Outside of menu 14 Auto pause 15 Set auto pause 16 Eneble auto pause 15 Set auto pause 15 Set auto pause 15 Set auto pause 15 Set auto pause 16 Firmware version 17 Troubleshooting 18 Safety Set day 18 Safety Set day 18 Safety Set day 18 Liability, warranty and copyright notice 19		
Q1 (22 7 NC 7 TIRe 8 DIST to DIS4 8 SEG A, SEG B, SEG C, SEG D, SEG E, SEG F, SEG G, SEG DP 8 BUXZEF 8 TB 8 Basic circuit 9 Properties of the components 10 7 segment displays 10 Checked displays 10 Checked displays 10 Effect of an acrylic glass 10 Effect of an acrylic glass 10 Calculate the series resistor for one LED 12 Calculate the series resistor for two LED 12 Calculate the series resistor for two LED 12 Robring in Control 13 Button functions 13 Button functions 13 Button functions 14 Wenu 14 Using the Countdown Timer - Outside of menu 14 Buzzer properties 13 Button function 14 Wenu 14 Using the Countdown Timer - Outside of menu <td></td> <td>7</td>		7
N.C. 7 TiRe 8 DIST to DIS4 8 SEG A, SEG B, SEG C, SEG D, SEG E, SEG F, SEG G, SEG DP 8 DIA & DIB 8 Buzzer 8 TB 8 Basic Circuit 9 Properties of the components 10 7 segment displays 10 Checked displays 10 Effect of an acyplic glass 10 Calculate the series resistor for two LED 12 Calculate the series resistor for two LED 12 Keyboard 13 Button functions 13 Relais 13 Butzer properties 13 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 15 Set auto pause 15 Set auto pause 15 Set auto pause 15 Set auto pause 15 Count direction 15		
TiRe 8 DIS1 to DIS4 8 SEG A, SEG B, SEG C, SEG D, SEG E, SEG F, SEG G, SEG DP 8 Buzzer 8 TB 8 Basic circuit 9 Properties of the components 10 7 segment displays 10 Clocked displays 10 Effect of an acrylic glass 10 Calculate the series resistor for one LED 12 Calculate the series resistor for two LED 12 Keyboard 13 Rotary encoder 13 Rotary encoder 13 Relais 13 Buzzer properties 13 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer progreties 13 Button functions 14 Wenu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Enable auto pause 15 Exit auto pause 15		
DIST to DIS4 8 SEG A, SEG B, SEG C, SEG D, SEG E, SEG F, SEG G, SEG DP 8 DIA & DIB 8 Buzzer 8 TB 8 Basic circuit 9 Properties of the components 10 7 segment displays 10 Chocked displays 10 Chocked displays 10 Chocked the series resistor for more LED 10 Calculate the series resistor for two LED 12 Keyboard 13 Button functions 13 Rotary encoder 13 Rolais 13 Buzzer properties 13 Button functions 14 Button functions 14 Button functions 14 Button functions 14 Wenu 14 Using the Countidown Timer - Outside of menu 14 Using the Countidown Timer - Outside of menu 14 Using the Countidown Timer - Outside of menu 14 Extatuo pause 15 Set auto pause <td></td> <td></td>		
DA & DIB Buzzer 8 Buzzer TB 8 Basic circuit Properties of the components 10 7 segment displays 10 Checked displays 10 Checked displays 10 Claculate the series resistor for one LED 12 Calculate the series resistor for two LED 12 Keyboard 13 Button functions 13 Rotary encoder 13 Relais 13 Buzzer properties 13 Button functions 14 Button functions 14 Wenu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Ext auto		8
Buzzer 8 TB 8 Basic circuit 9 Properties of the components 10 7 segment displays 10 Checked displays 10 Effect of an acrylic glass 10 Calculate the series resistor for one LED 12 Keyboard 13 Button functions 13 Relais 13 Buzzer properties 13 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Exit at op pause 15 Set at op pause 15 </td <td></td> <td>8</td>		8
TB 8 Basic circuit 9 Properties of the components 10 7 segment displays 10 Checked displays 10 Effect of an acrylic glass 10 Calculate the senies resistor for one LED 12 Calculate the senies resistor for two LED 12 Keyboard 13 Button functions 13 Relais 13 Butzer properties 13 Buzzer properties 13 Butzon functions 14 Wenu 14 Using the Countdown Timer - Outside of menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 15 Set auto pause 15 Set auto pause 15 Set auto pause 15 Set auto pause 15 Sol pause 15 Display mode setting 15 Info section 15 C number 16 Fi		8 8
Basic circuit 9 Properties of the components 10 7 segment displays 10 Checked displays 10 Effect of an acrylic glass 10 Calculate the series resistor for one LED 12 Keyboard 13 Button functions 13 Roday encoder 13 Ralais 13 Buzzer properties 13 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Set auto pause 15 Set auto pause 15 Count direction 15 Display mode setting 15 Info section 15 C number 16 Firmware version 16 Menu end 16 Attachment 17 The following error messages may occur		8
Properties of the components 10 7 segment displays 10 Checked displays 10 Effect of an acrylic glass 10 Calculate the series resistor for one LED 12 Calculate the series resistor for two LED 12 Keyboard 13 Button functions 13 Rotary encoder 13 Relais 13 Buzzer properties 13 Button functions 14 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer settling 14 Auto pause 15 Set auto pause 15 Exit auto pause 15	Basic circuit	
7 segment displays 10 Checked displays 10 Effect of an acrylic glass 10 Calculate the series resistor for one LED 12 Calculate the series resistor for two LED 12 Keyboard 13 Button functions 13 Relais 13 Buzzer properties 13 Button description 14 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Set auto pause 15 Count direction 15 Display mode setting 15 Info section 15 Info section 15 Info section 16 Menu end 16 Menu end 16 Menu end 16 Attachment 17 The following error messages may occur 17 Eri8 - No button in menu 17		
Checked displays		
Effect of an acylic glass 10 Calculate the series resistor for two LED 12 Calculate the series resistor for two LED 12 Keyboard 13 Button functions 13 Relais 13 Buzzer properties 13 Button description 14 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Set auto pause 15 Count direction 15 Display mode setting 15 Info section 15 Ic number 16 Firmware version 16 Menu end 16 Attachment 17 The following error messages may occur 17 Er8 - No button in menu 17 Er8 - No button in menu 17 Er9 - Menu item not defined 17 7 segment c		
Calculate the series resistor for two LED 12 Keyboard 13 B utton functions 13 Relais 13 Relais 13 Buzzer properties 13 Button description 14 B utton functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 Ic number 16 Firmware version 16 Menu end 16 Attachment 17 The following errors can occur 17 The following error messages may occur 17 Er8 - No button in menu 17 Er8 - No button in menu 17 Er8 - No button in menu 17 Er8 - No b	Effect of an acrylic glass	
Keyboard 13 Button functions 13 Rotary encoder 13 Relais 13 Buzzer properties 13 Button description 14 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Exit auto pause 15 Exit auto pause 15 Display mode setting 15 Info section 15 Info section 15 Ic number 16 Firmware version 16 Menu end 16 Attachment 17 Trobleshooting 17 The following error can occur 17 The following error messages may occur 17 Erf8 - No button in menu 17 Erf8 - No button in menu 17 Erf9 - Nemu item not defined 17		
Button functions 13 Relais 13 Buzzer properties 13 Button description 14 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause in 15 Set auto pause in 15 Exit auto pause in 15 Count direction in 15 Display mode setting in 15 Info section in 15 Ic number 16 Firmware version in 16 Menu end 16 Attachment 17 Troubleshooting in 17 The following error messages may occur in 17 Er89 - No button in menu in 17 Er89 - No button in menu in reference in the most defined in the most defined in menu in the most defined in the most defi		
Rotary encoder 13 Relais 13 Buzzer properties 13 Button description 14 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Exit auto pause 15 Exit auto pause 15 Exit auto pause 15 Count direction 15 Info section 15 Info section 15 Ic number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er8 - No button in menu 17 <tr< td=""><td></td><td></td></tr<>		
Buzzer properties 13 Button description 14 Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er89 - No button in menu 17 Er89 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Button description 14 Butun 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following error scan occur 17 The following error messages may occur 17 Erf8 - Ne button in menu 17 Erf9 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	
Button functions 14 Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 15 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er69 - No button in menu 17 Er69 - No button in menu 17 Fr69 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Menu 14 Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		14
Using the Countdown Timer - Outside of menu 14 Buzzer setting 14 Auto pause 15 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19	Button functions	14
Buzzer setting 14 Auto pause 14 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 Ic number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19	Menu	
Auto pause 14 Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 Ic number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er59 - No button in menu 17 Er59 - No button in menu 17 559 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Enable auto pause 15 Set auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Ers8 - No button in menu 17 Ers9 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Set auto pause 15 Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Erf8 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Exit auto pause 15 Count direction 15 Display mode setting 15 Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er59 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Count direction 15 Display mode setting 15 Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Info section 15 IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
IC number 16 Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19	Display mode setting	15
Firmware version 16 Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Menu end 16 Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Attachment 17 Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Troubleshooting 17 The following errors can occur 17 The following error messages may occur 17 Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 17		
The following errors can occur The following error messages may occur Er58 - No button in menu Er59 - Menu item not defined 7 segment characters Change log Safety Set day Liability, warranty and copyright notice 17 17 18 18 18 18 19		
The following error messages may occur Er58 - No button in menu Er59 - Menu item not defined 7 segment characters 18 Change log Safety Set day Liability, warranty and copyright notice 17 18 18 18 19		
Er58 - No button in menu 17 Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19		
Er59 - Menu item not defined 17 7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 17 Liability, warranty and copyright notice 17		
7 segment characters 18 Change log 18 Safety 18 Set day 18 Liability, warranty and copyright notice 19	~	
Change log18Safety18Set day18Liability, warranty and copyright notice19		
Safety 18 Set day 18 Liability, warranty and copyright notice 19	Change log	18
Set day Liability, warranty and copyright notice 18		
	Liability, warranty and copyright notice	19
	Table of Contents -	Page 2 of 20

Definitions	19
Liability	19
Warranty	19
Copyrightnotice	19
Disposal information	20
Impress	20

Safety

Follow the manual



The IC is only safe in operation if all instructions are read in this datasheet.

General understanding of safety

By the IC there are no hazard under normal use.

Intended Use

The IC is designed for driving small to middle displays.

The power should come from a safe transformer (also protected transformer) or a corresponding low voltage power supply for the circuit. Never use a higher voltage or direct mains voltage!

Concealed Hazards



following hazards may arise in case of wrong construction of the circuit and wrong handling of IC:

- With the direct connection to mains, it's a dangerous voltage on the IC and other components, use a safety transformer!
- 🔼 Reverse polarity and overloading the IC may cause in smoke. This smoke possibly contains toxic substances which must not be inhaled! Ventilate the room.
- Reverse polarity or overload of the IC can cause a hot surface on the IC or other component in the circuit.
 - There is a risk of burning when touching.
 - And flammable materials, for example Paper, can come in fire.
- Spalling of parts on reverse polarity or overloading of the IC. Wear during the initial commissioning eye protection.
- $f \Delta$ The pins of a IC are very pointed and sharp! Therefore, this may cause in sores in case of incorrect handling.
- Use always passing a ESD bracelet to avoid electric charges! The IC can be damaged if handling without an earthing tape and housing!

Modifications of the example circuit

The successfully built circuit may be damaged. Therefore check as appropriate all housing part and lines for damage. This applies in particular to parts of the directly (for example power cord and power supply) or indirectly come into contact with mains voltage.

Safety -Page 4 of 20

Application and function description

Function description

The IC SPM110X ... is a digital mono-flop IC with display and buttons for setup. It has a buzzer output for Sound notification that the time has expired and an output forswitching a load via relay, transistor, etc..

The IC is a programmed microcontroller of the AVR family by Atmel. The circuit can be used for different purposes, because the target file is free for download, the circuit can be arbitrarily Modified.

This IC has the standard **OnChip display technology** and is suitable for small displays. These can be connected directly to the IC and require only 4 additional resistors.

Functions

- Adjustable digital timer ranges from 1 second to 99 minutes and 59 seconds.
 - o The set time is stored in the internal EEPROM
 - o Easy to start, with just one button press
 - o Pause function interrupts the countdown
 - o Signal sounds after the time, for a preset time or upto press the button start-stop.
 - An output for switching loads, relays, solid relays or similar. After inverting transistor BC547C 100mA output load (or similar type).
- This IC has the Classic Screen display and the new default view, the differences are seen to www.stefpro.biz as gif video.
- Extra menu button to easily change the settings or press the start / stop button for 1 second to operate with 3 buttons or rotary encoder.
- LED test, at power up all the LEDs turned on for 1 second in order to facilitate the quality control
- It requires no additional IC's without voltage regulator.
- Low power consumption. Requires a power below

Application

- $\circ~$ For second exact exposure of PCBs, screen printing templates \dots
- o Precisely timed Baking of plastics
- Timed bonding
- Timed flow control

Functional states

The START button is to press for the state start and stop.

With button DOWN in state "Setting Wait" the time can be lowered in seconds. In state "Pause" the countdown can be stopped by this key.

With button UP in state "Setting Wait" the time can be increased in seconds. In state "start†and "pause" this key functions as start / pause button.

The functional states can be seen in Figure 1.




Abbildung 1: State diagram countdown mode

After reset / power up: Entry point after the reset and initialization.

Wait (setting): Setting the time is available, the time displayed on the screen is used as the next count down time. The Pin TiRe has a 0 (GND) at the output.

Countdown: In this operation, the time counted down in seconds and the decimal point (/SEGDP) flashes every second. Pin the TiRe has a 1 at the output so VCC potential.


Pause: The countdown is interrupted and the whole display flashes. Pin TiRe has a 0 (GND) at the output.

Stop phase (buzzer): In this state, the TiRe pin is reset to 0 (GND) and the buzzer pin is up for 3 seconds (or set time) or upto pressing the button Start to 0 (GND).

Technical data

- o Voltage (VCC): 3 V 5 V
- o Current: 20 mA (at 5 V)
- o Power: approximately 100mW (at 5 volts)
- o Number of Pins: 28
- o Display Power: directly to the controller is the maximum LED current 40mA
- Clock frequency: 8MHz
- o Other properties, refer to the datasheet for Atmel® ATMega8, ATMega88, ATMega168, ATMEGA168P, ATmega328P

Construction description



Pin assignment

Reset

Reset input to reset the microcontroller is normally not required. In case of higher EMC requirements a 100nF capacitor should be soldered to ground!

VCC

Operating voltage (3 V - 5 V)

AVCC

Analog operating voltage (VCC $\pm\,0.3$ V), there should be a coil with about $10\mu\text{H}$ connected between VCC and AVCC.

AREF

Internal analog reference voltage should be blocked with a 1 nF ceramic capacitor

GND

Ground

Q1, Q2

The connecting of the 8MHz quartz is shown in Figure 1 $\,$




Figure 1: Connection of qaurtz

C1 and C2 are 20pF to 27pF ceramic capacitors (depending on the quartz) Q is an 8MHz quartz

N.C.

Do <u>not connect</u>, connect to no other signal!

TiRe

Output for the time relay, it has to reinforce to switch a relay with a transistor (for example BC547C).

Operating mode State Comment

"Setting Wait"	0 (GND)
"Countdown"	1 (VCC)
"Pause"	0 (GND)
"Stop phase"	0 (GND)

DIS1 to DIS4

The respective anode 7-segment display. DIS1 is the tens of minutes and DIS4 the ones digit of seconds.DIS6 simultaneously provides the mass for the button. Should be wired as in the wiring diagram of the basic circuit.

SEG_A, SEG_B, SEG_C, SEG_D, SEG_E, SEG_F, SEG_G, SEG_DP

 $Cathode\ terminals\ for\ LED\ segments\ of\ the\ 7-segment\ displays.\ Furthermore\ keys\ are\ connected\ to\ Seg\ A,\ Seg\ B,\ Seg\ C,\ Seg\ D\ .$

DIA & DIB

Pin A and B of the rotary encoder.

Buzzer

On this connector a buzzer can be connected as an acoustic alarm optionial. The plus pole must be connected to VCC pin of the buzzer, the minus pin must connected with $\hat{a} \in \mathbb{C}$ Summer $\hat{a} \in \mathbb{C}$.

TB

Tap to verify the accuracy of the time base, min. 0,999 99 kHz and max. 1.000 01 kHz, the larger is the different from the 1 kHz the less accurate the IC. Production pin. The quartz can be adapted by firmware, see menu item "Calibrate quartz" or by adapting the quartz capacitors.

Basic circuit





Figure 2: Basic circuit of SPM1200P

Properties of the components

7 segment displays

The seven-segment display LD1 must have a common anode. Via R1 the brightness of the LEDs can be set, it should be noted, that the maximum



Checked displays

Manufactor no. Hersteller-Nr.	Manufactor Hersteller	Color Farbe	Current Strom	Brightness Helligkeit
0.39 in - 10 mm				
SA 39-11 SRWA	KINGBRIGHT	Red- Rot	32mA	✓
SA 39-11 GN	KINGBRIGHT	Green- Grün	28mA	_
0.52 in - 13,3 mm				
SA52-11SRWA	KINGBRIGHT	Red- Rot	32mA	✓
SA52-11LSRWA	KINGBRIGHT	Red- Rot	32mA	(Minimal brighter - Minimal heller)
SA52-11EWA	KINGBRIGHT	Red- Rot	30mA	_
SA52-11YWA	KINGBRIGHT	Yellow- Gelb	29mA	x
SA52-11LYWA	KINGBRIGHT	Yellow- Gelb	29mA	X
SA52-11GWA	KINGBRIGHT	Green- Grün	28mA	_
SA52-11LGWA	KINGBRIGHT	Green- Grün	28mA	_
SA52-11QBWA-D	KINGBRIGHT	Blue- Blau	10mA	✓
LTS-546AP	Lite-On	Red- Rot	~30mA	х
TDSR5160	Vishay Semiconductors	Red- Rot	~30mA	х
TDSG5150	Vishay Semiconductors	Green- Grün	28mA	✓
0.56 in - 14,2 mm				
SA 56-11 EWA	KINGBRIGHT	Red- Rot	32mA	х
SA 56-11 GWA	KINGBRIGHT	Green- Grün	28mA	x
0.8 in - 20,32 mm				
SA08-11SRWA	KINGBRIGHT	Red- Rot	32mA	✓
SA08-11EWA	KINGBRIGHT	Red- Rot		Testis still pending - Test steht noch aus
SA08-11YWA	KINGBRIGHT	Yellow- Gelb	29mA	✓
SA08-11GWA	KINGBRIGHT	Green- Grün	28mA	х
SA08-11PBWA	KINGBRIGHT	Blue- Blau	10mA	_
HDSP-8601	Agilent	Green- Grün	28mA	_
2.3 in - 56,9 mm				
SA23-12SRWA	KINGBRIGHT	Red- Rot	-	✗ (impossible-unmöglich)
SA23-12EWA	KINGBRIGHT	Red- Rot	-	✗ (impossible-unmöglich)
SA23-12YWA	KINGBRIGHT	Yellow- Gelb	-	✗ (impossible-unmöglich)
SA23-12GWA	KINGBRIGHT	Green- Grün	-	✗ (impossible-unmöglich)
4.0 in – 100 mm				
SA40-19SRWA	KINGBRIGHT	Red- Rot	-	✗ (impossible-unmöglich)
SA40-19EWA	KINGBRIGHT	Red- Rot	-	✗ (impossible-unmöglich)
SA40-19YWA	KINGBRIGHT	Yellow- Gelb	-	✗ (impossible-unmöglich)
SA40-19GWA	KINGBRIGHT	Green- Grün	-	✗ (impossible-unmöglich)

- ∘ ✓ Works fine Funktioniert perfekt
- — Works but not fine Funktioniert, aber nicht zu empfehlen
- Doesn't work Funktioniert nicht
- $\circ \quad \textbf{X} \ \, \text{Not tested, would not work directly Nicht getestet, da nicht direkt m\"{o}glich.}$

Effect of an acrylic glass




Figure 3: Differences of display readability brightness level 1




Figure 4: Differences of display readability brightness level 25

The displays in figure 3 and 4 are from left to right:

- o SA52-11SRWA
- o SA52-11EWA
- o SA52-11YWA
- SA52-11GWA
- o SA52-11QBWA-D



Figure 5: SA08-11SRWA left without and right with contrast pane with back light.



Figure 6: SA08-11SRWA left without and right with contrast pane without back light.

Below with and above without back light.

Because the displays are multiplexed (only one LED is lights at the same time for a maximum of 6 microseconds) to minimize component count and power consumption, not all 7-segment displays are usable.


Also note, that the displays which can work with 10 mA constant current, not implicitly work with 10 mA pulsed current. All displays have been limited with a 100 ohm resistor.

The brightness of the display is designed for the brightness conditions in a living room or laboratory. Since the circuit is optimized for minimum components and power consumption, the readability is limited with direct irradiation by spotlight or sunlight without a contrast panel very limited and with better.


It is recommended to place a contrast panel in front of the display, see figure 6 and 5.

Note: The menu is always displayed with 100% brightness.

Calculate the series resistor for one LED



Calculate the series resistor for two LED




- UDS ≈ 0
- ILED < 35 mA

Keyboard

Button functions

The keyboard consists of three to four buttons. It is expressly recommended to use digital compatible switches. The diodes D1 to D4 are for blocking display faults when pressing 2 and more keys.

The remote control of the controler is simply possible by parallel adding or replacing the button with NPN transistors.



Menu Opens the menu, next setting

Plus Function key, in general + or on

Minus Function key, in general - or off

Which button assignment to which pin, please refer to the example diagram.

The rotary encoder generates Menu + when turning to the right and Menu- when turning to the left. If the rotary encoder is equipped with a button, this can be used to start / stop and for the menu.

To open the menu you have to press the menu or StartStop button for a long time. Use the menu button to navigate forward.

The double button for the menu and StartStop must be pressed for about 2 seconds for the menu.

Rotary encoder


The rotary encoder is available for setting the default values. Turning to the right is equivalent to pressing the plus key and turning the left key to the minus key. Each notch generates an increment or decrement.

Relais

In the basic circuit is shown how a relay or something like that can be connected.T1 used R5 as a series resistor, T1 is operated as an amplifier and also as an inverter. For T1 and R5, other components may be used.A direct connection of a coil or a load with more than 20 mA is not recommended direct with the SPM1100 - SPM1102.D6 is idle, the diode when operating with coils.If the controller frequently triggers a reset or has other mistakes, instead of a transistor a optocoupler should be used.

Buzzer properties

The buzzer B1 must be self-producing and have a minimum voltage of VCC. Does the buzzer have not VCC, a series resistor have to be installed. The buzzer may further maximum of 40mA directly from the IC SPM1200P. The plus pole of the buzzer have to be applied to VCC and the minus pin of the buzzer have to connected to the IC.D1 is the idle diode when operating with coils.



Button description

Button functions

Menu+ Opens the menu, next setting

Menu- Opens the menu, previus setting

Plus Function key, in general + or on

Minus Function key, in general - or off

Which button assignment to which pin, please refer to the example diagram.

The rotary encoder generates Menu + when turning to the right and Menu- when turning to the left. If the rotary encoder is equipped with a button, this can be used to start/ stop and for the menu.

To open the menu you have to press one the menu buttons. Use the menu+ button to navigate forward and the menu- button to navigate backward.

The double button for the menu and StartStop must be pressed for about 2 seconds for the menu.

Menu

Level 1 Level 2

Using the Countdown Timer - Outside of menu

Auto pause → Set auto pause → Exit auto pause ひ

Count direction↓

Display mode setting↓

Info section↓

IC number↓

Firmware version↓

↓: Next step in main menu.

→: Next step in sub menu.

: The submenu starts again.

Using the Countdown Timer - Outside of menu



The countdown timer is operated by 3 buttons. • S1 is the start and stop button. If the cour

- S1 is the start and stop button. If the countdown timer in the pause mode, the timer can be restart with this button.
- S3 is the plus key, it increments the time. If the countdown timer is running, this button paused the countdown.
- S4 is the minus key, it decrements the time. If the countdown timer is running, this button stops the countdown.

These buttons are available only when the menu is not open, otherwise the keys are used by the menu.

Buzzer setting



With the button plus and minus the buzzer settings can be select.0: No


- ${\bf 1:3\,seconds\,after\,the\,counter\,ends}$
- 2: 9 seconds after the counter ends
- 3: infinitely until keystroke after the counter ends

Auto pause




Auto pause

With + you enter the sub-menu auto pause.




Count direction



With plus key is counted up and with minus key down. The direction does not change if the timer is already started, this take over until a restart.

Display mode setting



With keys plus and minus display mode setting Select $\,$


- $\circ~$ C: Classic, buzzer beeps continuously
- S: Standard, the buzzer beeps with interruptions

Info section



This indicates the start the information area

IC number




Chip number

Firmware version



Firmware version

Menu end



End

IC / device type

Firmware version

Example, it might be something else at this point.

End of the menu, hide automatically after 2 seconds.

Attachment

Troubleshooting

This is a general listing of possible errors and error codes associated with the SPM1xxx series.

The following errors can occur

- o IC gets hot
 - power supply not okay: measure VCC power supply, eventl. too big.
 - IC is plugged in reverse polarity.
- o display remains dark and buzzer remains idle
 - Power supply not okay, re-measure VCC power supply.
 - Quartz does not vibrate: Quartz defect or quartz capacitors are defective or too large.
 - Reset pin is grounded or too small Capacitor is connected.
- The display stays dark and at the beginning there is only a short beep
 - Bootloader button is pressed at power on
 - Bootloader button is shorted and defective.
- The display stays dark and at the beginning there is only one beep
 - Firmware was not updated correctly during the last firmware update, try firmware update again.
 - firmware is broken for another reason, replace IC.

The following error messages may occur

Er58 - No button in menu


The button is not defined in the menu item.

Er59 - Menu item not defined

menu item is not defined.

7 segment characters

The symbolism of each character:



Change log

Safety

20.03.2017 - 1.0.3 - ADD Add ESD note

Set day

23.04.2017 - 1.0.4 - ERROR Bugfix wrong title, this sets the day not the month.

Liability, warranty and copyright notice

Definitions

- "Programmed IC": IC which was developed by StefPro and can only used with a minimum basic circuit.
- "Manufacturer of the whole device": The manufacturer of the whole device, the natural or legal person is mounted a device which can be made to function without special knowledge. E.G. Simple connection to the network via a euro, safety plug or by connecting to a power supply.

Liability

- Although the information contained in this document has been checked very carefully for accuracy and completeness, for errors and omissions can not be held liable. StefPro reserves the right to any time change any portion of the described hardware and software features.
- StefPro delivers only the "programmed IC", a basic circuit and possibly an example circuit, but these are not tested for CE and EMC. The
 "Manufacturer of the whole device" requires the valid VDE, CE and EMC is comply with regulations.
- There is no liability for damages incurred directly by or in the application of the "programmed IC", as well as for damage caused by chemical or electrochemical effects of water or generally from abnormal environmental conditions.
- "Programmed IC's" by StefPro may not be used in critical equipment. At disregard exclusively the responsibility of "Manufacturer of the whole
 device."

Theseinclude:

- medical devices for implanting or life obtained.
- Critical equipment for space, aerospace and traffic.
- Other important life components or systems, where an error is fatal.
- All developed with a "programmed IC" by StefPro modules and devices must be the responsibility of the "Manufacturer of the whole device" sufficiently tested to detect any defects.

Warranty

- StefPro warranty only for the programmed IC and their firmware. The warranty is exclusively limited for the replacement of the IC within the warranty period for obvious defects in the hardware, and programming error.
- Warranty does not extend the warranty period or starts a new period again.
- Additional or deviating claims are excluded, especially claims for damages arising out of the product for damage. This will not affect claims based on inalienable rules under the product liability law.

Copyrightnotice

The circuitry and firmware from StefPro is protected by copyright.. Unauthorized reproduction or distribution of programmed IC's with this program or any portion of it. This is pursued bothcriminal and civil law, and may result in severe penalties and compensation for damages.

Disposal information

Do not dispose devices in household garbage!

This modules or devices comply with the EU directive on electronic and electrical equipment (WEEE regulation) and therefore may not be disposed of with household waste. Dispose of the device over your local collection center for electronic equipment!



WEEE-Reg.-Nr.:

DE 58929072 (StefPro UG (haftungsbeschränkt) & Co. KG)

DE 78089358 (StefPro Einzellunternehmen bis zum 01.01.2015)

Impress

StefPro™ UG (haftungsbeschränkt) & Co. KG - Softwareentwicklung für Prozessoren

Dipl. Ing. (FH) Stefan Nannen

Theilenmoorstr. 11

26345 Bockhorn - Germany

Phone: +49-4452-709175

Web:<u>http://www.stefpro.biz/</u>

E-mail: info@stefpro.biz